

ABB MEASUREMENT & ANALYTICS | TECHNICAL DESCRIPTION

ScreenMaster RVG200 Paperless recorder



Online prediction of the optimum coagulant dosage for potable water treatment using the RVG200 paperless recorder

Measurement made easy

Online prediction of coagulation dosage for potable water treatment

Introduction

All life requires water to survive. From plants to human beings, water consumption is vital to maintain good health and prolong life. However, water is also home to smaller organisms and contamination such as bacteria and viruses, some of which can be detrimental to the health of the organisms that may be consuming the water.

The World Health Organization (WHO) are responsible for providing a set of general standards of water quality that are followed in countries where better local standards are not implemented.

Developed countries, such as those in Europe, have vigorous standards in place for drinking water that mean the quality of water is high enough that it can be drunk directly from the tap (faucet). Potable or drinking water treatment involves the removal of contaminants from raw water to produce water that is pure enough for human consumption without any long- or short-term effects on human health as a result of that consumption. The type of substances that must be removed are viruses, bacteria, algae, fungus and suspended solids. Certain minerals (for example, iron and manganese) must also be removed as high concentrations are harmful if consumed.

This Technical Description focuses on using ABB's RVG200 paperless recorder to perform online coagulant dose prediction in a water treatment plant using the following product build: RVG200.A6.A6.H6.Y0.*.0.*.*.A.*.*Y-N1.N2.N5.

It explains why this process is important and details how to configure the recorder.

What is coagulation?

Coagulation is the term used when referring to the action or process of a liquid (for example, blood), changing to a solid or semi solid state. The initial stages of water treatment involve the removal of solids from the water.

Large debris or trash is first removed from the water by a screen. Other large non-floating debris is then separated from the water by gravity. However, not all solids in the water are large enough to be removed in this way. It is at this point that coagulation is employed as the next step in removing the solids. In terms of water treatment, coagulation is a process that involves the addition of a chemical to the water that causes the smaller particles to clump together to form larger aggregates that can then be removed more easily. This chemical, normally a metallic salt such as iron or aluminium, has a positive electrical charge that is the opposite to the negative charge on the particles that are suspended in the water. Rapid mixing ensures the chemical dissolves and is distributed evenly throughout the water.

The introduction of the opposing electrical charge neutralizes the negative charge on the particles causing them to stick together, thus forming larger particles. The water then flows into another tank where it is stirred very slowly to bring the particles together and form large particles or 'flocs'. This step is called flocculation.



The coagulation process

Coagulant dose prediction

The purpose of a coagulant dosing system is to calculate and dispense the optimum amount of the coagulant to facilitate the chemical process and allow the particulates to become big enough to be removed from the water through the processes of sedimentation and filtration. It does this by using a series of measurements that are fed through a pre-configured equation that uses the instantaneous values of water color, turbidity, flow, pH and a number of operator set 'K' (constant) values. These are based on the pretreatment water quality and coagulant being used, to calculate the dose demand:

(K1 × raw color) + (K2 × raw turbidity) + K3 + pH trim + clarified color trim

Where:

- K1 = color contribution factor*
- K2 = turbidity contribution factor*
- K3 = base coagulation dose
- K4 = coagulant type factor

When calculated, the dose demand is used in a further equation:

dose demand × flow × K4/1440

This calculates the actual required dose rate in I/m that is used subsequently to control a coagulant dosing pump in the system.

Note. The 'K ' values are supplied by the water treatment customer and are unique to every installation.

Water color measurement

Colorimetry or colorimetric chemistry is a method of measuring the concentration of a sample based on the absorption of light, of a particular wave length, that can be measured and converted to a concentration value of the light absorbing substances within the sample. The amount of light absorbed in this type of measurement varies in accordance with the Beer-Lambert Law that defines a simple linear relationship between the absorption of light of a sample and the concentration of that sample.

In the case of water treatment, coagulant dosage adjustment is based on the natural color of the water. This is used to measure the smallest of particles or dissolution of chemicals that cannot be detected with the naked eye. The more particles contained within the water the cloudier it will be and the more light it absorbs.



Beer-Lambert Law graph

AW637 color analyzer



Turbidity measurement

Turbidity is considered a good indicator of water quality. It is the measurement of the degree that water loses its transparency due to suspended solids within it. The WHO states that turbidity in drinking water should be less than 5 NTU (Nephelometric Turbidity Units) but ideally less than 1 NTU. The device used for measuring turbidity is a Nephelometer and it works by passing light through a sample where it is scattered by any suspended particles that are present within the sample. The intensity of the scattered light is detected and measured using a sensor that is placed at a 90° angle to the light source.

In the case of water treatment, the turbidity and color of the water is used to ascertain the level of treatment that is required.



Turbidity measurement schematic

ATS430 turbidity and total suspended solids sensor



pH measurement

To predicate the coagulant requirement, the amount of particles in the water, together with the electrical charge on those particles, must be determined. pH is an important variable because particle charge can be affected significantly in low pH raw waters and alkali must be added together with coagulant to create the correct conditions for flocculation to occur. Natural pH and reactions involving algae can create changes in the particle charge and thus affect the coagulant dose required.

To predict the amount of coagulation required, the effects of pH on the system are taken into account using a 'pH trim' component. This determines the range of raw water pH over which additional coagulant is required and incorporated into the overall dose; and the extra magnitude that is required.

AP300 general purpose pH/Redox sensor



Clarified color trim

For online coagulant dosage prediction, a closed loop control arrangement is used. To achieve this, the apparent treated water color is measured and compared to a required water color; the value of dosage can then be adjusted to achieve the required color. This modification is known as the **Clarified color trim** and is used in the dosage calculation together with all the other measured values and pH trim value.

Configuring the RVG200

Configuration of the RVG200 begins in the same way as any other process. The number of process groups, the individual physical inputs and associated alarms are all configured as for a standard recorder to the requirements of the process.

For the coagulation prediction application, the following physical analog inputs are required:

- raw water color (analog I/P 1)
- raw water turbidity (analog I/P 2)
- raw water Flow (analog I/P 3)
- raw water pH (analog I/P 4)
- clarified water color (analog I/P 5)

...and the following physical digital inputs:

- raw color sample status (hybrid digital I/P 2)
- clarified color sample status (hybrid digital I/P 3)
- maintenance hold (hybrid digital I/P 1)

The recorder's Math & Logic and custom linearizers are then used to calculate the color and pH trim and the actual dose demand and rate.

Calculating the pH trim value

To calculate the pH trim, a 4 to 20 mA (pH) signal is introduced to the recorder, passed through a custom linearizer (as a % of range) and converted to a value that represents 0 to 20 mg/l (% of range) (Note. This value is an example only.)



The output of the linearizer is then used as the pH trim value in the dosage calculation.

Calculating the color trim value

To calculate the color trim value, the clarified color input is introduced to a custom linearizer (as a % of range) and converted to a value that represents -20 to +20 mg/l (% of range)

(Note. This value is an example only.)



The output of the linearizer is then used as the color trim value in the dosage calculation.

When the linearizer has been configured it is assigned as the linearizer type on its associated input:

Channel 3.13	∢ III		×
Analog I/P B1			
Type milli	amps		80
Linearizer Type Cus	tom lineariz	er 1	80
Electrical range low 4			60
Electrical range high 20			60
			

For further information on configuring and using custom linearizers – refer to Technical Description <u>TD/RandC/003-EN</u> – ScreenMaster and ControlMaster | Process recorders, controllers and indicator | Configuring and using custom linearizers.





Math and logic equations

The following flow chart provides an over-view of the logic used within the RVG200's math blocks and logic equations and how they link together to provide the calculation values required. The logic equations are used to provide conditional digital signals within the configuration.



Math block configuration

Math block 1

Math block 1 is a multiplexing math block. This means it has a switch function, the output of which depends on the state of a digital signal. If the digital signal is not present (logic 0) the output will be one value and, if present (logic 1), another value:

Maths	X
Maths 1 Maths 2 Maths 3 Maths 4>	
Block Type Equation Editor	00
Equation Mux(aiB2,0,le1B)	61
Reset source None	61
Engineering range -10.0 - 10.0 mg/l	.⊡∥
Tag ColTrimOrZero	60
Fault detect level 10 %	60
Fault Detect Direction Upscale	00

In this example, if the digital signal is not present, the output is the value of analog input B2 (aiB2). If the digital signal is present the output is a constant value of 0. This enables the calculation to be reset if required. The digital signal is logic equation 1 (le1B).

Math block 2

Math Block 2 is a multiplexing math block. In this example, if the digital signal is not present the output is the result of math block 1. If the digital input is present the output is the result of math block 2. The result of math block 2 is returned to math block 2 so, in the event of a failure, the last known good value can be held until the system has recovered. The digital signal is logic equation 3 (le3B).

Maths	×
Maths 1 Maths 2 Maths 3 Maths 4>	
Block Type Equation Editor	60
Equation Mux(mb1,mb2,le3B)	60
Reset source None	60
Engineering range -10.0 - 10.0 mg/l	60
Tag Colour Trim	60
Fault detect level 10 %	60
Fault Detect Direction Upscale	60

Math bock 3

Math block 3 is the dose demand equation. Custom view analog values are used as sources to enable a constant value to be entered via the front panel when using a customcreated operator view.

Maths	X	
Maths 1 Maths 2 Maths 3 Maths 4>		
Block Type Equation Editor	61	
Equation (cva1*aiA1)+(cva2*aiA	60	
Reset source None	<u>@</u> /	
Engineering range 0.0 - 150.0 mg/l	@∥	
Tag Raw Dose Demand	@∥	
Fault detect level 10 %	60	
Fault Detect Direction Upscale	60	

Maths			×
Enter maths e	quation	•	
< (cva1*aiA1)-	+(cva2*aiA2)+cva	3+aiB1+mb2	>
* /	+ -	, ()
Trigonometric	Power	Anlg Sources	Del
Log	Special	Digital Sources	с
Statistical	Switch	Constant	ОК

Where:

cva1 = K1 value cva2 = K2 value cva3 = K3 value aiA1 = analog input 1 aiA2 = analog input 2 aiB1 = analog input B1 mb2 = math block 2

Math block 4

Math block 4 is a multiplexing math block. In this example, if the digital signal is not present the output is the result of math block 3. If the digital input is present the output is the result of math block 4. The result of math block 4 is returned to math block 4 so, in the event of a failure, the last known good value can be held until the system has recovered. The digital signal is logic equation 4 (le4B).

Maths	×
Maths 1 Maths 2 Maths 3 Maths 4>	
Block Type Equation Editor	60
Equation Mux(mb3,mb4,le4B)	60
Reset source None	61
Engineering range 0.0 - 150.0 mg/l	60
Tag Dose Demand	60
Fault detect level 10 %	00
Fault Detect Direction Upscale	60

The output of this math block is assigned to a 4 to 20 mA output from the fitted hybrid module to provide the dose demand signal.

Math block 5

Math Block 5 is the dose rate calculation

Maths	×
< Maths 5 Maths 6 Maths 7 Maths 8>	
Block Type Equation Editor	00
Equation (mb4*aiA3*cva4/1440*	00
Reset source None	60
Engineering range 0.0 - 3000.0 ml/m	60
Tag Raw Dose Rate	60
Fault detect level 10 %	00
Fault Detect Direction Upscale	60

Maths				×
Enter maths e	quatior	า		
< (mb4*aiA3*c	va4/1440	*1000)		>
* /	+	-	, (
Trigonometric	Pov	ver	Anlg Sources	Del
Log	Special		Digital Sources	; с
Statistical	Switch		Constant	ок

Where:

mb4 = math block 4 aiA3 = analog input A3 cva4 = K4

The constant values of 1440 and 1000 (to provide a value in ml) are programmed manually as whole numbers in the equation.

Math block 6

Math block 6 is a multiplexing math block. In this example, if the digital signal is not present the output is the result of math block 5. If the digital input is present the output is the result of math block 6. The result of math block 6 is returned to math block 6 so, in the event of a failure, the last known good value can be held until the system has recovered. The digital signal is logic equation 5 (le5B).

Maths	×
< Maths 5 Maths 6 Maths 7 Maths 8>	
Block Type Equation Editor	60
Equation Mux(mb5,mb6,le5B)	61
Reset source None	61
Engineering range 0.0 - 3000.0 ml/m	61
Tag Dose Rate	60
Fault detect level 10 %	00
Fault Detect Direction Upscale	60

The output of this math block is assigned to a 4 to 20 mA output from the fitted hybrid module and is used to drive the dosing pump.

...Configuring the RVG200

... Math block configuration

Math block 24

In this example math block 24 is configured to keep this feature separate from the other math blocks. It has a single constant of 1, with an engineering range of 0 to 1 and is used as the basis for a timer

Maths	×
< Maths 21 Maths 22 Maths 23 Maths 24	
Block Type Equation Editor	
Equation 1	60
Reset source None	60
Engineering range 0.0 - 1.0	60
Tag Process Time	60
Fault detect level 10 %	
Fault Detect Direction Upscale	60

The math block is then assigned to a recording channel.



A totalizer is then enabled on the recording channel. The totalizer serves as a counter to update the dose calculation with the most current clarified color trim value at a predetermined interval that is configurable by the operator using the custom screen. It can also be reset manually through the front panel as required.

Channel 4.23	(III)	×
< Totalizer A B			
Setup Sto	d 7,Count up	,Wrap on	60
Tag/Units P-1	lime, minute		60
Stop/Go/Reset Go, None, Logic equatio		60	
Timed Reset Off		60	
Count range 0-0)		60
Log update Of	f, None		60
Count rate/Cut off 0.0	01667, 0.0		00

Logic equation configuration

Logic equation 1

Custom view digital 1 is the operand in this equation. The equation is assigned as the reset source for the totalizer. This enables the totalizer to be reset to zero when the digital signal is activated via the User button on the custom operator view.



Logic equation 2

This logic equation outputs 1 when the totalizer is not wrapped and the clarified color sample has not failed. It is an indication of the system status and its output is used in logic equation 3.

Logic equation editor	×
LE 1 LE 2 LE 3 LE 4 LE 5 LE 6>	
Operand/Operator 1 Wrap pulse 4.23A and	00
Operand/Operator 2 Hybrid Dgtl I/P C3 End	60
Eqtn tag & log enable Logic2, Off	60

Logic equation 3

This logic equation produces a signal to put the calculation into a holding status in the event of a deliberate calculation reset or failure of the clarified color sample.

Logic equation editor	×
LE 1 LE 2 LE 3 LE 4 LE 5 LE 6>	
Operand/Operator 1 Logic equation 1 xor	60
Operand/Operator 2 Logic equation 2 or	60
Operand/Operator 3 Hybrid Dgtl I/P C3 End	60
Eqtn tag & log enable Maint Hold / IP Fail, Off	80

Logic equation 4

This logic equation produces a signal to put the calculation into a holding state in the event of a signal failure or a deliberate maintenance hold.

Logic equation editor	X
LE 1 LE 2 LE 3 LE 4 LE 5 LE 6>	
Operand/Operator 1 Hybrid Dgtl I/P C1 or	60
Operand/Operator 2 AIN A1 fail state or	60
Operand/Operator 3 AIN A2 fail state or	0
Operand/Operator 4 AIN A4 fail state or	0
Operand/Operator 5 AIN A5 fail state End	
Eqtn tag & log enable Maint Hold / IP Fail, Off	60

Logic equation 5

This logic equation is used to loop the dose rate calculation back on itself to hold the math block output while also producing a digital logic 1 signal to select the multiplexer source.



Logic equation 6

This logic equation is used in its own recording channel as a system status indication and is visible in the operator view.



Channel 1.01	(- III >	×		
Setup Logic equation 6 Totalizer A B					
Digital on tag	eck!		@∥		
Digital off tag Au	to				
Tag Sy:					

Logic equation 23

This logic equation provides a digital signal in the event that any of the analog inputs fail.

Logic equation editor	×			
< LE 19 LE 20 LE 21 LE 22 LE 23 LE 24				
Operand/Operator 1 AIN A1 fail state or	@∥			
Operand/Operator 2 AIN A2 fail state or	@∥			
Operand/Operator 3 AIN A3 fail state or	@∥			
Operand/Operator 4 AIN A4 fail state or	60			
Operand/Operator 5 AIN A5 fail state End	60			
Eqtn tag & log enable Relay Drive1, Off	₿0			

Logic equation 24

This logic equation comprises the signals in **Logic equation 23** and all remaining analog failure signals, together with the digital inputs indicating the raw- and clarified-color status and is assigned to a relay output.

Logic equation editor	×
< LE 19 LE 20 LE 21 LE 22 LE 23 LE 24	
Operand/Operator 1 Logic equation 23 or	60
Operand/Operator 2 AIN B1 fail state or	60
Operand/Operator 3 AIN B2 fail state or	60
Operand/Operator 4 Hybrid Dgtl I/P C2 or	60
Operand/Operator 5 Hybrid Dgtl I/P C3 End	60
Eqtn tag & log enable Relay Drive, Off	60

Relay		×
Relay F1		
	Source Logic equation 24	00
	Polarity Negative	60

Custom operator view

This example configuration relies on the ability to enter values manually to ensure the equation is calculating the correct number. These values (K) change depending on the standard to which the water is being treated, the contaminant level and the coagulant that is being used.

The RVG200 has the option to create customized operator views, enabling the creation of custom view analog and digital signals. These can be assigned to User buttons on the screen to enable manual input of an analog constant value and also a virtual digital signal. In this example configuration, the custom screen is used to display 6 manually entered variables:

K-Values			<u></u>	08/03/19 10:15:41	
	Live Values				
Instantaneous Colour Trim 0.0 mg/l		n /	Dose Demand 0.0 mg/		
Colour Tri 0.0	m to Pump mg	//	Dose 0.0	Rate ml/m	
**** - WARNING - **** Changing of ANY Value WILL Affect the Coag Dose Calc.					
Change K1	Current 1.000	Pro	icess time (r	ninutes]	
K2 K3 K4	1.000 1.000 1.000		50	Reset	

(example custom screen, view can be customized for customer requirements)

K1, 2, 3 and 4 are all user-adjustable analog values. Touching any of the buttons displays a keypad entry window to enable manual entry of each K value:

K-Values				08/03/19 10:15:49	
Instan	K1 (0.0	0010.	000)		
Col	1.000				mg/l
	7	8	9	-	.ml/m
Chang Cha	4	5	6		e Calc.
К	1	2	3	X	5]
К		0	Del	~	set

Enter the required value and touch <u></u>

The process time is linked to the totalizer. When the process time button is touched, the totalizer's preset-,

predetermined- and intermediate-values are displayed. The values can all be changed as required:

☆K-Values	es 08/03/19 10:15:56	
Count range		
Preset count 0		
Predetermined count 50	<u></u>	
Intermediate count 99999999	<u></u>	
	 Image: A set of the set of the	

Select the time (in minutes) to use as the recalculation time and touch

The custom digital value is assigned on this example custom screen to the we button. This digital value is the reset source for the totalizer.

For more information on how to use the Custom View Editor software – refer to Instruction <u>INS/RandC/002</u> – ScreenMaster RVG200 | Paperless recorder | Custom View Editor instructions



Click on the following link or scan the QR code for more information on the analytical instrumentation that can be used in this application that ABB also manufacture.

Analytical measurement





ABB Limited Measurement & Analytics Howard Road, St. Neots

Cambridgeshire, PE19 8EU UK Tel: +44 (0)1480 475 321 Fax: +44 (0)1480 217 948 Email: instrumentation@gb.abb.com

ABB Inc.

Measurement & Analytics

125 E. County Line Road Warminster, PA 18974 USA Tel: +1 215 674 6000 Fax: +1 215 674 7183

abb.com/recorders



We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.